




SLM Satellite

Salamander 2.4 I2C Mode-0

Configuration Guide

Jan22



Introduction

This configuration guide applies to the Salamander 2.4 I2C Mode-0 ONLY.
For any other version please use the appropriate guide as several configuration options are different.


The Salamander 2.4 I2C Mode-0 has 2 operation modes: Standalone and Slave.


In Standalone Mode, the unit has no interaction with other units and is only accessible via web for configuration, command or readings of sensors. In this mode, the access control features are available with local recording of cards and permissions. A limited log of card readings and events is also available.

It is highly recommended to connect the unit to a wifi network.

If a wifi network is not available, the unit will automatically start the wifi access point feature, creating it's own wifi network named S-AP_XXXXXX.

In Slave mode, the unit has to be connected to a Master controller, using a wifi network. The access control features rely on the configuration of the Master and all events are recorded in the Master database. The Master controller provides several extended features like advanced date/time permission settings for the access control, recording of logs for longer and graphic features.





Configuration

Connect for the first time

When powered for the first time, the Salamander Satellite has no wifi configuration and starts a wifi Access Point (AP).

1. Connect the USB power cord and wait for 1 minute.
2. Connect to the WiFi network with SSID = S-AP_XXXXXXXX (the XXXXXXXXX may be any combination of numbers). Make sure the DHCP is on. The password is "Admin001"
3. Open your browser and type to "192.168.4.1". This is the IP address of the Satellite when working as AP. You will get the home screen of the Satellite.

The screenshot displays the Salamander Satellite web interface. At the top, the title "Salamander Satellite" is followed by a navigation menu with buttons for Home, Command, Authorized Cards, Setup, Settings, Register, Logs, Transfer Cards, Change Password, Reboot, Update, Logout, and Factory Reset. Below this, the "Network Information" section shows the IP Address as 192.168.4.1, Subnet Mask as 255.255.255.0, Default Gateway as 192.168.4.254, and MAC Address as C4:5B:BE:62:BA:1D. The "WiFi Network" section shows the WiFi Connection as "Working as Access Point Standalone" and the Messaging Status as "Inactive - (State: -1)". Below these sections are "Digital Inputs" (Switch 1: ON, Switch 2: ON) and "Access Control System" (Reader 1: Not Connected, Lock-0: OFF, Lock-1: OFF, Relay-2: OFF, Relay-3: OFF). Red arrows point from external text to the IP address and the WiFi connection status.

Network Information		WiFi Network	
IP Address:	192.168.4.1	WiFi Connection:	Working as Access Point Standalone
Subnet Mask:	255.255.255.0	Messaging Status:	Inactive - (State: -1)
Default Gateway:	192.168.4.254		
MAC Address:	C4:5B:BE:62:BA:1D		

Digital Inputs


Switch 1: ON
Switch 2: ON

Access Control System

Reader 1 : Not Connected
Lock-0 : OFF
Lock-1 : OFF
Relay-2 : OFF
Relay-3 : OFF

IP configuration when working as AP

Working as Access Point Standalone = Not connected to a Master



Configuration

Login

To change the configuration of the Satellite a login is required.

1. Click on Setup. The login screen will show-up.
2. Use Admin / Admin001 to start the session

If you change the password make sure you remember it. Resetting a password requires factory support.

Salamander
Satellite


Home Command Authorized Cards Setup Settings Register Logs Transfer Cards

Change Password Reboot Update Logout **Factory Reset**

Login

User:

Password:



Configuration - Network

Network (if working as standalone with no connection to a wifi network, skip this step)

To connect to an existing WiFi network,

1. Go to Setup, Select the wifi network and provide the password.
2. Next step provide a static IP Address, Subnet Mask and Default Gateway for the Satellite.
3. If working as Slave Provide the Master Controller IP Address. If not (as Standalone) leave this field empty.
4. Click on Reboot. The Satellite will restart with the new network settings. Change your computer settings and access the Satellite with the new IP.

**Salamander
Satellite**

Home Command Authorized Cards Setup Settings Register Logs Transfer Cards

Change Password Reboot Update Logout **Factory Reset**

Setup


IP Address:

SubNet Mask:

Default Gateway:

Master Controller IP:
Leave empty for Standalone mode

[Change WiFi Network](#)



Configuration - Settings

Some basic configuration settings are configured here.

Salamander Satellite

[Home](#) [Command](#) [Authorized Cards](#) [Setup](#) [Settings](#) [Register](#) [Logs](#) [Transfer Cards](#)
[Change Password](#) [Reboot](#) [Update](#) [Logout](#) [Factory Reset](#)

Settings


Satellite Name:

Activate relay at: Our relay boards work acting the relay with an high signal. If using 3rd party relays this may be different.

Output 1: Lock
Output 2: Lock The satellite has 4 Outputs. The Outputs 1 and 2 can be configured as Locks and be part of the access control system being activated when an authorised card is used or an open lock command is received.

Synch Time: seconds Only used when in Slave mode to synchronise with the Master

Alarm Mode: There are 3 modes available.
Mode 0: The satellite does not process any information from the sensors. If in Slave configuration, sensor readings are sent to the Master.
Mode 1: When sensing movement the satellite starts relay 3 and 4 in sequence turning on a light or sound alarm.
Mode 2: Same as Mode 1 but only starts relays 3 and 4 if the input 1 if on



Configuration - Register

Register (if working as standalone skip this step)

The Satellite automatically discovers any sensors, card readers and relays connected to it. If working as Slave, relays and data from the sensors have to be registered with the Master Controller.

In the Register page, click on Register button and wait for the confirmation message on the screen.

Go back to the Home screen.

View site information **der**

Satellite

Home Command Authorized Cards Setup Settings Register Logs Transfer Cards

Change Password Reboot Update Logout **Factory Reset**


Register

Reader 1 : **Not Connected**
Lock_20-1 : **Assigned** [28]
Lock_20-2 : **Assigned** [29]
Relay_20-3 : **Assigned** [30]
Relay_20-4 : **Assigned** [31]

No temperature sensors connected

Switch 1 : **Not Assigned**[0]
Switch 2 : **Not Assigned**[0]

Register



Configuration - Check Settings

Reading the Home screen

Check if the network settings are correct.

Check the connectivity and registration with the Master. If properly connected, the Satellite will have a Controller ID. If communicating with the Master, the Messaging Status will show Active.

Salamander Satellite

Home Command Authorized Cards Setup Settings Register Logs Transfer Cards
Change Password Reboot Update Logout **Factory Reset**

Network Information		WiFi Network	
IP Address:	192.168.1.61	WiFi Connection:	Vodafone-DE51D3 (64%)
Subnet Mask:	255.255.255.0	Connected to Master:	<u>192.168.1.9</u>
Default Gateway:	192.168.1.254	Satellite Controller ID:	20
MAC Address:	C4:5B:BE:62:BA:1D	Messaging Status:	Active - (State: 0)

Digital Inputs


Switch 1: ON
Switch 2: ON

Check the status of the inputs (usually switches)

Access Control System

Reader 1 : Not Connected
Lock_20-0 : OFF
Lock_20-1 : OFF
Relay_20-2 : OFF
Relay_20-3 : OFF

Check also if the Card Reader is connected and the status of the relays (on / off)



Configuration - Other Features

Command

Provides a way to turn switches **on and off**.

If switches are configured as Locks, it turns the door lock relay **on** for approximately 5 seconds.

Authorised Cards

Lists authorised cards.

When in Standalone configuration, cards recently detected by the card reader are displayed here and you can manage which should be authorised or not.

In Slave configuration, the list of authorised cards is provided by the Master.

Logs

Displays the list of recent errors, card readings and events.


Transfer Cards

This feature is only available in Standalone configuration and allows Satellites nearby to share their list of authorised cards. Mostly used when several racks are in the same room and have the same authorised cards for opening the doors.


Update

Used for firmware updates.

Configuration - Wired Connections




Configuration - Wired Connections



Sample - Wired Connections

Alarm Mode 1



Sample - Wired Connections

Alarm Mode 2

